

EK-BM873-TM-004

H.H. MARTENS & ZOON B.V.  
Statendamweg 75 - Oosterhout  
tel. 01620 - 22000

**BM873 1090.08**  
**restart/loader**

1st Edition, January 1974  
2nd Printing (Rev), April 1974  
3rd Printing (Rev), October 1974  
4th Printing (Rev), February 1975

Copyright © 1974, 1975 by Digital Equipment Corporation

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors which may appear in this manual.

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts:

DEC	PDP
FLIP CHIP	FOCAL
DIGITAL	COMPUTER LAB
UNIBUS	

## CONTENTS

	Page
<b>CHAPTER 1</b>	<b>DESCRIPTION</b>
1.1	INTRODUCTION . . . . . 1-1
1.2	GENERAL DESCRIPTION . . . . . 1-1
1.3	FUNCTIONAL DESCRIPTION . . . . . 1-1
<b>CHAPTER 2</b>	<b>INSTALLATION AND CHECKOUT</b>
2.1	INSTALLATION . . . . . 2-1
2.1.1	Start Address Selection . . . . . 2-1
2.1.2	Jumper Selection . . . . . 2-2
2.1.3	CPU Addressing with Volatile Memory . . . . . 2-2
2.2	CHECKOUT . . . . . 2-3
<b>CHAPTER 3</b>	<b>PROGRAMMING</b>
3.1	POWER FAIL PROGRAMMING . . . . . 3-1
3.2	REGISTER DESCRIPTION . . . . . 3-1
<b>CHAPTER 4</b>	<b>OPTIONS</b>
4.1	USER CUSTOMER PROGRAM FOR THE BM873-YA . . . . . 4-1
<b>CHAPTER 5</b>	<b>INTERFACE</b>
<b>CHAPTER 6</b>	<b>ENGINEERING DRAWINGS</b>
<b>APPENDIX A</b>	<b>DEVICE STARTING ADDRESSES</b>

## ILLUSTRATIONS

Figure No.	Title	Page
1-1	Remote Start Timing . . . . .	1-3
1-2	Memory Read Timing . . . . .	1-4
2-1	External Interface Circuit Diode Matrix . . . . .	2-2
4-1	Sample ROM Program Data Sheet . . . . .	4-2

## TABLES

Table No.	Title	Page
1-1	Description of BM873 Versions . . . . .	1-2
1-2	BM873 Specifications . . . . .	1-2





# CHAPTER 1

## DESCRIPTION

### 1.1 INTRODUCTION

This manual describes the operation and theory of the BM873 Restart/Loader. This option is intended for use with the PDP-11 family of processors. The BM873

- serves as general purpose loader for processors of the 11 family,
- contains bootstrap loaders for all common devices,
- provides the capability of loading with a "hidden console",
- permits starting from several sources e.g., pushbutton, Watchdog Timer, MODEM control, power fail, etc.,
- gives PDP-11 systems an initial program load capability,
- contains at least four starting addresses, and
- permits the calling of a special user ROM program.

It is assumed that the reader is thoroughly familiar with the operation of the PDP-11 processor with which this option is used.

### 1.2 GENERAL DESCRIPTION

The BM873 option is contained on a quad-height, extended length module that plugs into a small peripheral controller (SPC) slot. There are four versions of the BM873: YA, YB, YC, and YD. They are described in Table 1-1.

The programs contained in the BM873 can be loaded either from the processor console (Load Address and Start), by a JMP instruction in the program, or by an external contact closure or voltage level. An 8-pin Mate-N-Lok connector is used for the external interface. BM873 specifications are listed in Table 1-2.

### 1.3 FUNCTIONAL DESCRIPTION

The BM873 consists of two basic sections: the Restart Sequencer and the ROM.

Figure 1-1 shows the remote start timing. The Restart Sequencer takes contact closures or voltage levels and, after filtering and delaying, sets one of four Start Address Select flip-flops. The setting of one of the flip-flops causes the Begin Load Sequence flip-flop to set; this, in turn, initiates two one-shots to create a BUS AC LO/BUS DC LO



**Table 1-1**  
**Description of BM873 Versions**

Version Designation	ROM Size	Description
BM873-YA	128 words (256 words optional)	Contains bootstrap loader programs for several peripheral devices (RF11, RK11, TC11, etc.).
BM873-YB	256 words	Contains bootstrap loader programs for the devices contained in the YA version, plus programs for the Massbus devices.
BM873-YC	256 words	Contains bootstrap loader programs for the devices contained in the YA version, plus the program for the DU11 Synchronous Interface.
BM873-YD	256 words	Contains bootstrap loader programs for the TC11 DECTape, RH11/RP04 Disk, and the DTE20 10/11 Interface.


**Table 1-2**  
**BM873 Specifications**

Capacity	
BM873-YA	128 words, read only (256 words optional)
BM873-YB, YC, YD	256 words, read only
Word length	16 bits
ROM cycle time	500 ns
Voltage requirements	+5 V $\pm 5\%$ -15 V $\pm 5\%$
Current requirements	1.0 A max @ +5 V 2.0 mA max @ -15 V
Operating temperature	10° to 50° C
Humidity	20% to 95%

sequence. The processor responds to the sequence by performing its normal power-down and power-up trap routines. Prior to the power-up sequence, however, the BM873 option asserts 773000 on the Unibus Address Lines. As a result, when the Program Counter (PC) and Processor Status Word (PSW) are restored, the data is taken from locations 773024/26 (nonvolatile memory systems) or from locations 773224/26 (volatile memory systems). Both of these addresses are locations within the BM873 option. The data from 773\*24 is 173000; the data from 773\*26 is 340, establishing a priority level of 7.

The data read from 773\*24 (173000) will have an offset address ORed onto Offset Address bits 8 through 1, giving a range of 173000 to 173776. The offset address bits are enabled by one of the four Start Address Select flip-flops via a diode matrix (Paragraph 2.1.1). Each bootstrap loader program has its own starting address, and it is this address that is selected via the offset address bits.

In the BM873-YB, some of the bootstrap loader programs have two starting addresses. The first address automatically selects unit zero and the second address selects the unit specified in the switch register. See Appendix A for device starting addresses for all versions.



11-2408

Figure 1-1 Remote Start Timing




The following sequence of operations would be typical:

- Close external switch and wait for switch filter delay.
- Assert AC LO; wait 6 ms.
- Assert DC LO for 6 ms; then wait 8 ms.
- Drop AC LO and assert address 773000.
- Wait for INIT to finish.
- The processor enters power-up routine.
- The BM873 option recognizes the fetch of address 773024 or 773224 and asserts 173XXX plus the 8-bit offset address to the data lines.
- The processor reads location 773026 or 773226 which is always 000340 (priority level 7).
- The processor fetches the next instruction from the ROM in address range 773000–773776. From this point, the bootstrap loader program contained in the ROM has control. (In the PDP-11/35 and PDP-11/40 systems, the PSW is fetched before the PC.)

If an actual power fail occurs in a nonvolatile memory system, the BM873 option does nothing, and the power-down and power-up traps work in the normal manner. If an actual power fail occurs in a volatile memory system, the power-up jumpers in the processor are set for 173224. During power-up the processor will fetch from 173224; the combination of address 773224 and no external lines asserted will cause the BM873 option to assert line 1 as a default case. Thus, in this case, the offset address selected for line 1 becomes the bootstrap loader call for power fail.

Data is read from the ROM in two bytes. Address bits 7 through 1 are present at all times via the bus receivers. Address bit 0 is generated on the module. A0 is always clear prior to a read cycle. The setting of A0 clocks the first byte into a holding register and simultaneously changes the address to gate the second byte to the output drivers. After a delay of about 200 ns, the output gates are enabled and the ROM data is placed on the Unibus. SSYN is asserted about 150 ns later, completing the read cycle. Figure 1-2 illustrates memory read timing.



11-2407

Figure 1-2 Memory Read Timing



## CHAPTER 2

# INSTALLATION AND CHECKOUT

### 2.1 INSTALLATION

Normally the BM873 Restart/Loader is installed at the factory and no further installation is required. However, if this option is added to an existing system, it may be necessary to add wiring to make the AC LO and DC LO signals available. These signals are provided on the PDP-11/05 and PDP-11/45 processors, and on the DD11-B. On the PDP-11/15, PDP-11/20, PDP-11/35, PDP-11/40, and the DD11-A it is necessary to ensure that the SPC slot containing the BM873 has BUS AC LO and BUS DC LO wiring available as follows:

Pin CV1 to B01F1 or B04F1 (BUS AC LO)

Pin CN1 to B01F2 or B04F2 (BUS DC LO)

If the wiring is not present, it must be added by hand-wiring, using a wire color different from that of the existing backplane wiring.

#### NOTE


The BM873 option must be on the CPU side of any bus buffer.

#### 2.1.1 Start Address Selection

Each of the four external interface circuits has an associated address which must be specified for that circuit to be addressed. Each address consists of a fixed high-order portion (773XXX) and a low-order portion (bits 8 through 1) that is selected by adding or cutting diodes (Figure 2-1). With the diode in, a 1 is placed on the Unibus. With the diode out, a 0 is placed on the Unibus. When adding diodes, a low-wattage iron should be used and care should be taken with the plated mounting holes, so that the plating is not lifted from the laminate by the heat. The diodes (DEC type 664 or 1N3606) should be positioned so that their cathodes point toward the gold fingers of the module.

Appendix A lists starting addresses for various devices used with the BM873-YA, -YB, -YC and -YD Restart/Loaders. The three rightmost digits of the address represent the low-order portion to be selected via diodes.

The diagnostic program for this option contains a listing of the loader program in the comments portion of the Data Compare section. That diagnostic will be updated to contain the starting addresses and listing of future variations.



11-2406

Figure 2-1 External Interface Circuit Diode Matrix

### 2.1.2 Jumper Selection

The BM873 module contains three jumpers that are marked with the numerals 1, 2, and 3. Jumpers 1 and 2 are used to compensate for differences between the PDP-11/40 and 11/35 and all other PDP-11 family processors. Jumper 1 should be installed when the option is used with either the PDP-11/40 or the PDP-11/35. Jumper 2 should be installed for use with any other processor in the PDP-11 family. For the BM873-YD, jumper 1 is always installed and jumper 2 is always removed. Resistor R3 is also removed on the BM873-YD.

Jumper 3 controls access to an extra 128 words of ROM. When this jumper is cut, additional addresses from 773400 to 773776 become available. For the BM873-YB, -YC, and -YD versions, this jumper is always cut.

### 2.1.3 CPU Addressing with Volatile Memory

When this option is used in computers with volatile memory, the power fail trap address must be jumpered to 773224 if automatic reloading is desired.

For a PDP-11/45 CPU, install jumpers W6, W3, and W1 on the M8100 board. This will provide an address of 773224.

For a PDP-11/40 CPU, connect jumper W7 on the M7235 board for a binary 1. This jumper will provide an address of 7732XX. The last two digits are provided by jumpers 4 and 2.



## 2.2 CHECKOUT

The diagnostic program for the BM873 option is MAINDEC-11-DZBMD-D. This program starts with a dialogue and is self-explanatory. As new ROM programs are implemented, this diagnostic may be modified. However, the basic version may be used on all option variations as long as the user visually checks the ROM data following the first pass.

The diagnostic contains the instructions for its own operation. The opening dialogue establishes which option variation (-YA, -YB, etc.) is being tested.

The first part of the report is a general description of the project and its objectives. It also includes a brief history of the project and a list of the people involved.

The second part of the report is a detailed description of the project and its objectives. It also includes a list of the people involved.



## CHAPTER 3

# PROGRAMMING

This device is a Read-Only Memory and requires no programming. However, certain factors must be considered in system programming as the following paragraphs explain.

### 3.1 POWER FAIL PROGRAMMING

With the BM873 option installed, the power-down/power-up routines may require modification, depending on the bootstrap used. Use of the external interface causes the power-fail sequence in the CPU when AC LO is detected going low; the power-up trap program is not used, and, therefore, not restored.

This is not a problem when a bootstrap loads into core and overwrites location 24, because the new program will set up the power-fail routine. However, if the new program does not reload location 24, the next power-fail sequence (may be real) will find the power-up restore program instead of the power-down routine.

This condition can be resolved by the power-fail routine testing this option with any DATI instruction. The combination of this option and a real power-fail will cause the DATI to perform in a normal manner. The combination of this option and the external interface active (causing the AC LO and trap) will cause a nonexistent device trap (no SSYN) to location 4.

```

                                MOV                #1S,@#4                ; TRAP CATCHER
                                CLR                @#6
                                TST                @#173000              ; DEV BLIND?
                                NOP
2S:    MOV                #PWRUP,@#24                ; REAL PWR FAIL
                                (SAVE ROUTINE)
1S:    HALT
```

#### Example 1

The above program works because this option goes "blind" (will not return SSYN) when it has been activated by an external interface signal. This condition continues from the assertion of AC LO until the release of DC LO.

### 3.2 REGISTER DESCRIPTION

There are no registers in this device. There are four flip-flops that can be loaded for diagnostic purposes but they cannot be read.

1. 2000-2001  
2. 2002-2003

3. 2004-2005

4. 2006-2007

5. 2008-2009

6. 2010-2011

7. 2012-2013

8. 2014-2015

9. 2016-2017

10. 2018-2019

11. 2020-2021



## CHAPTER 4

### OPTIONS

#### 4.1 USER CUSTOM PROGRAM FOR THE BM873-YA

Two etched circuit positions on the BM873-YA board provide an extra 128 words of ROM. To add this extra memory capacity, Jumper 3 must be cut, permitting address recognition of all 256 words.

Figure 4-1 is a sample ROM program data sheet that can be helpful in programming the ROMs. Columns 1 and 2 contain the PDP-11 program listing. From the address data in column 1, the ROM starting address can be determined and the offset diodes cut (diode = 1; no diode = 0). The data in column 2 must be expressed in binary form as in columns 3 and 4. (Note that byte 1 is moved to the line below that of the original entry.) The eight binary digits for each byte are then shifted into columns 5 and 6 under the ROM B and ROM A headings, respectively. Columns 7 and 8 contain the resulting ROM address in binary and decimal form, respectively. Column 8 consists of four columns of decimal addresses, distinguished by the configuration of the 2 MSB of the binary address. Each program data sheet contains 64 ROM locations (32 words), hence four sheets are required to encode all 128 words. Therefore, only one of the four subcolumns of decimal addresses actually applies for each sheet, and the other three should be crossed out to avoid confusion. The 2-column checklist between columns 7 and 8 can be used for checkoff purposes, e.g., checking off ROMs as they are blasted.

A blank program data sheet is included in Chapter 6 to assist the user in programming the read-only memory of the BM873.

Customers who wish to create their own programs can purchase PROMs from integrated circuit vendors or distributors. Some distributors have programming capabilities so that programmed ROMs can be purchased. The following PROMs have been found acceptable:

Intersil type 5603A  
Monolithic Memories Inc. type 6300

The following PROMs have not been tested but according to the manufacturer's data should be acceptable. Any PROM that is specified to be "pin compatible with the 74187" should work in this application.

National Semiconductor type DM8573  
Signetics type 82S26

ROM Program Data Sheet - 32<sub>10</sub> Word Block

Program Listing		Octal List		ROM "B"		ROM "A"		ROM Addr.		76		76		76	
Addr.	Data	Byte "1"	Byte "0"	3 2 1 0	3 2 1 0	3 2 1 0	5 4 3 2 1 0	A	B	00	01	10	11		
173000	010702	00010001	11000010	1100	0010	0010	000000	✓	✓	0	64	128	192		
173002	000455	00000001	00101101	0010	0010	1101	000010	✓	✓	1	65	129	193		
173004	177462	00000001	00110010	0011	0011	0010	000100	✓	✓	2	66	130	194		
173006	000005	00000000	00000001	0000	0000	0010	000110	✓	✓	3	67	131	195		
173010	010702	00010001	11000010	1100	0010	0010	000010	✓	✓	4	68	132	196		
173012	000451	00000001	00101001	0010	0010	1001	000101	✓	✓	5	69	133	197		
173014	177406	00000001	00000110	0000	0000	0110	001100	✓	✓	6	70	134	198		
173016	000451	00000001	00101001	0010	0010	1001	000010	✓	✓	7	71	135	199		
173018	000451	00000001	00101001	0010	0010	1001	000100	✓	✓	8	72	136	200		
173020	000451	00000001	00101001	0010	0010	1001	000101	✓	✓	9	73	137	201		
173022	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	10	74	138	202		
173024	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	11	75	139	203		
173026	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	12	76	140	204		
173028	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	13	77	141	205		
173030	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	14	78	142	206		
173032	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	15	79	143	207		
173034	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	16	80	144	208		
173036	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	17	81	145	209		
173038	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	18	82	146	210		
173040	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	19	83	147	211		
173042	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	20	84	148	212		
173044	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	21	85	149	213		
173046	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	22	86	150	214		
173048	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	23	87	151	215		
173050	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	24	88	152	216		
173052	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	25	89	153	217		
173054	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	26	90	154	218		
173056	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	27	91	155	219		
173058	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	28	92	156	220		
173060	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	29	93	157	221		
173062	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	30	94	158	222		
173064	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	31	95	159	223		
173066	000451	00000001	00101001	0010	0010	1001	000110	✓	✓	32	96	160	224		
173068	000451	00000001	00101001	0010	0010	1001	000111	✓	✓	33	97	161	225		
173070	176716	00000001	11001110	1100	1100	1100	111000	✓	✓	34	98	162	226		
173072	000005	00000000	00000001	0000	0000	0101	111010	✓	✓	35	99	163	227		
173074	010702	00000001	11000010	1100	1100	1101	111011	✓	✓	36	100	164	228		
173076	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	37	101	165	229		
173078	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	38	102	166	230		
173080	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	39	103	167	231		
173082	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	40	104	168	232		
173084	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	41	105	169	233		
173086	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	42	106	170	234		
173088	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	43	107	171	235		
173090	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	44	108	172	236		
173092	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	45	109	173	237		
173094	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	46	110	174	238		
173096	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	47	111	175	239		
173098	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	48	112	176	240		
173100	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	49	113	177	241		
173102	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	50	114	178	242		
173104	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	51	115	179	243		
173106	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	52	116	180	244		
173108	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	53	117	181	245		
173110	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	54	118	182	246		
173112	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	55	119	183	247		
173114	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	56	120	184	248		
173116	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	57	121	185	249		
173118	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	58	122	186	250		
173120	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	59	123	187	251		
173122	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	60	124	188	252		
173124	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	61	125	189	253		
173126	000451	00000001	00101001	0010	0010	1001	111111	✓	✓	62	126	190	254		
173128	000451	00000001	00101001	0010	0010	1001	111110	✓	✓	63	127	191	255		

Figure 4-1 Sample ROM Program Data Sheet



## CHAPTER 5

### INTERFACE

The external interface consists of four separate high-impedance receivers with 4.7-kilohm resistors in series with each one. A -15 V source is provided through 10 kilohms to facilitate the use of contact closures. The external interface also accepts single-ended voltage inputs. A signal of 0.5 mA at -4 V or greater will cause a Restart sequence. The maximum permissible input is  $\pm 25$  V.

These inputs are filtered with RC networks and Schmitt triggers and have a time delay of approximately 10 to 15 ms. The signal must remain for at least 150 ms. Only one external line may be active at a time; two or more active at the time of the sample will cause a race condition until one wins, but the result will be indeterminate.

The interface connector is an 8-pin male Mate-N-Lok (DEC Part Number 12-09340-01). Five pins (DEC Part Number 12-09378) are required for connection--placed as shown in Figure 2-1.

# INTRODUCTION

The purpose of this study is to investigate the effects of various factors on the growth and development of the human body. The study is based on a review of the literature and a series of experiments conducted over a period of six months. The results of the study are presented in the following sections.

The first section discusses the factors that influence growth and development, including genetics, nutrition, and environment. The second section describes the methods used in the study, including the selection of subjects and the design of the experiments. The third section presents the results of the study, showing the effects of the various factors on growth and development. The fourth section discusses the implications of the study for future research and for the development of interventions to promote healthy growth and development.



## CHAPTER 6

# ENGINEERING DRAWINGS

This chapter contains the 4-sheet engineering drawing of the BM873 (D-CS-M873-0-1) and a blank program data sheet for use in programming the read-only memory of this option. Use of these sheets is described in Chapter 4 of this manual.

0-10-2018

0-10-2018 at 10:00

0-10-2018 at 10:00



L E4 MUS

47

c

10

14

NATION		DESCRIPTION				PART NO.		ITEM NO.	
PARTS LIST									
C									
DRN		K.O. Davis		DATE		11-10-73		<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">digital</div> <div> <b>EQUIPMENT CORPORATION</b>  <small>MAYNARD MASSACHUSETTS</small> </div> </div>	
CHKD BY		H. J. Davis		DATE		11/30/73			
ENG.		H. J. Davis		DATE		11-30-73			
PROG. ENG.		H. J. Davis		DATE		11-30-73			
PROG.		H. J. Davis		DATE		11-30-73			
NEXT HIGHER ASSY				TITLE		RESTART LOADER			
B-DD-BM873-0				SIZE CODE		NUMBER		REV.	
A NO.				DCS		M873-0-1		C	
SCALE NONE				DIST.					
SHEET 1 OF 4									

1

D

C

REV.

C

NUMBER

M873-0-1

SIZE

D

B

REF	—	—	WORD LISTING OF YB ROM CONTENTS	B-AP-M873-0-14	56
—	REF	—	WORD LISTING OF YA ROM CONTENTS	B-AP-M873-0-9	55
REF	—	—	ROM LISTING FOR 23092 A2	K-RL-M873-0-13	54
REF	—	—	ROM LISTING FOR 23091 A2	K-RL-M873-0-12	53
REF	—	—	ROM LISTING FOR 23090 A2	K-RL-M873-0-11	52
REF	—	—	ROM LISTING FOR 23089 A2	K-RL-M873-0-10	51
—	REF	—	ROM LISTING FOR 23045A2	K-RL-M873-0-8	50
—	REF	—	ROM LISTING FOR 23044A2	K-RL-M873-0-7	49
A/R	A/R	W1,W2,W3	JUMPER	9107560-1	48
1	—	E20	IC 74187	23092-A2	47
QTY	QTY	QTY	REF DESIGNATION	DESCRIPTION	PART NO.

A

## PARTS LIST

M873-YB  
M873-YA  
M873-0

TITLE

RESTART LOADER

SIZE

D CS

NUMBER

M873-0-1

REV.

C

SCALE

—

SHEET

2 OF 4

DIST.









Choose one  
of four  
sheets. Cross

Sheet of 4

ROM Program Data Sheet - 32<sub>10</sub> Word Block

1	2	3	4
1	2	3	4
48	112	176	240
49	113	177	241
50	114	178	242
51	115	179	243
52	116	180	244
53	117	181	245
54	118	182	246
55	119	183	247
56	120	184	248
57	121	185	249
58	122	186	250
59	123	187	251
60	124	188	252
61	125	189	253
62	126	190	254
63	127	191	255

1874

Jan	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Feb	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	
Mar	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Apr	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	
May	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Jun	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Jul	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Aug	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Sep	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	
Oct	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Nov	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	
Dec	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31



# APPENDIX A

## DEVICE STARTING ADDRESSES

BM873-YA Starting Addresses

Address	Device Type
773000	RF11 DECdisk
773010	RK11 Disk
773020	Transfer to address contained in switch register
773030	TC11 DECTape
773050	TM11 DECmagtape
773100	RP11 Disk Pack
773144	RC11 Disk
773210	KL11/DC11 Console TTY Reader
773230	TA11 Cassette
773312	PC11 Paper Tape Reader

BM873-YB Starting Addresses

Address	Device Type
773000	RH11/RS03/RS04 Disk (Unit zero)
773002	RH11/RS03/RS04 Disk (Unit specified in switch register)
773030	RK11 Disk (Unit zero)
773032	RK11 Disk (Unit specified in switch register)
773070	TC11 DECTape
773110	TM11 DECmagtape
773136	RF11 DECdisk
773150	RH11/TU16/TM02 Tape Drive
773212	RC11 Disk
773230	RH11 Device Combination (Unit zero)*
773231	RH11 Device Combination (Unit specified in switch register)
773320	RH11/RP04 Disk (Unit zero)
773322	RH11/RP04 Disk (Unit specified in switch register)
773344	Transfer to address contained in switch register
773350	RP11 Disk Pack (Unit zero)
773352	RP11 Disk Pack (Unit specified in switch register)
773510	KL11/DL11 Console TTY Reader
773524	TA11 Cassette (Unit zero)
773526	TA11 Cassette (Unit specified in switch register)
773620	PC11 Paper Tape Reader

\*If the TM02/TU16 is selected, the value in the console switch register is the position of the TM02 on the RH11, instead of the unit number on the TU16 drive. The slave unit number (number on TU16) should still be zero.

# BM873-YC Starting Addresses

Address	Device Type
773000	RF11 DECdisk
773010	RK11 Disk
773020	Transfer to address contained in switch register
773030	TC11 DECTape
773050	TM11 DECmagtape
773100	RP11 Disk Pack
773144	RC11 Disk
773210	KL11/DC11 Console TTY Reader
773230	TA11 Cassette
773312	PC11 Paper Tape Reader
773400	DU11 Synchronous Interface

# BM873-YD Starting Addresses

Address	Device Type
773000	Transfer to address contained in switch register
773014	TC11 DECTape
773304	RH11/RP04 Disk
773534	DTE20 10/11 Interface



## Reader's Comments

BM873 RESTART/LOADER  
EK-BM873-TM-004

Your comments and suggestions will help us in our continuous effort to improve the quality and usefulness of our publications.

What is your general reaction to this manual? In your judgment is it complete, accurate, well organized, well written, etc.? Is it easy to use? \_\_\_\_\_

---

---

---

What features are most useful? \_\_\_\_\_

---

---

---

What faults do you find with the manual? \_\_\_\_\_

---

---

---

Does this manual satisfy the need you think it was intended to satisfy? \_\_\_\_\_

Does it satisfy *your* needs? \_\_\_\_\_ Why? \_\_\_\_\_

---

---

---

Would you please indicate any factual errors you have found. \_\_\_\_\_

---

---

---

Please describe your position. \_\_\_\_\_

Name \_\_\_\_\_ Organization \_\_\_\_\_

Street \_\_\_\_\_ Department \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip or Country \_\_\_\_\_

CUT OUT ON DOTTED LINE

Fold Here

Do Not Tear - Fold Here and Staple

FIRST CLASS  
PERMIT NO. 33  
MAYNARD, MASS.

BUSINESS REPLY MAIL  
NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

Postage will be paid by:

Digital Equipment Corporation  
Technical Documentation Department  
146 Main Street  
Maynard, Massachusetts 01754





**digital**

**DIGITAL EQUIPMENT CORPORATION  
MAYNARD, MASSACHUSETTS 01754**